500x190mm

MOES

Large LCD screen smart thermostat

WiFi 230V 4A/5A/16A

For Water Heating/Boiler/Electric Heating

- Write scenario like Geo-Fift Mode, can also deactivate Handicapped, Vacation Mode and the Function/Antifreezing temperature.
- Support air-outlogic GPS alerts external or manual air-equipped, to allow activation/deactivation in the Anticipation.
- Vaultfor scanner to code GPS for your manual activation at Portopia, to allow Installation or Introduction de fonctions
- Chronotemplis GPS map, intuitu mystanis gyaskagnes rai
- Kuidas ühendada GPS, siis aktiveerimine või deaktiveerimine Kodumasina
- Cum să conectați la GPS, apoi activați sau dezactivați Mașina de spălat
- Как подключить GPS, затем включить или выключить Стиральная машина
- كيفية توصيل GPS، ثم تشغيل أو إيقاف تشغيل غسالة
- GPS 연결 방법, 그런 다음 켜거나 끄는 방법 세탁기

Thank you for purchasing our products, please read the following terms before installation and use:

- Please ensure this product is suitable for use in your country before purchase.
- Before installation or maintenance, please make sure to cut off the power.
- Please strictly follow the wiring diagram for wiring installation.
- Before operation to the wall, please confirm that the fixtures are suitable for this product.
- Do not pull the cable too hard, otherwise the product will be damaged.
- If a hard plastic wire is used in the installation process, it must be bent to an appropriate angle in advance.
- Please do not disassemble the device.
- Please contact the after-sales service for equipment failure, please do not try to repair it yourself.
- The contents of this manual are only for manual to check again, in case normal and safe use, and keep this manual properly.

Product overview

This series of thermostats are designed to meet the different scenarios of floor heating application.Wi-Fi version supports the remote control of the thermostat via mobile phone app, combined with programming setting, the desired temperature can be automatically reached at the time you can conveniently control the heating system.

In the box you will find:

Screws	2pc
Wall anchor	2pc
User manual	1pc

Technical data

Model: 4700

Supply voltage: AC100-240V, 50/60Hz

Consumption: <1W; Max 5W (Wi-Fi screen + 3W Max)

Temperature setting range: 5-95℃

Temperature accuracy: 0.5℃ / 1℃

(The units works when the temp. is 2℃ above or 2℃ below the set temp.)

Switch deviation: 0.5-10℃ Factory setting 1℃

Ambient temperature: 0-40℃

Protection level: IP21

Housing material: PC (Flammable:V0)

Frequency Band: 2402GHz-2480MHz

Maximum Radio Transmit Power: <20dBm

Features

- ✓ Customized exclusive temperature plan – up to 6 events allowed to set per day
- ✓ Set sharp design delicate and elegant
- ✓ Large LCD screen better user experience

Dimension(mm)

Before wiring and installing

1. Read these instructions carefully. Failure to follow them could cause damage to the device or cause dangerous hazards.
2. Check the voltage, power of the thermostat and load on the product to make sure the product is suitable for your application.
3. The thermostat is a limited, supervised device with built-in.
4. After installation is complete, check our product operation correctly according to this manual.
5. The thermostat contains a hot capacity to share with the altitude of less than 2000m above sea level. Please rating of the thermostat is used in areas with altitude of 2000m to 4000m.

Warnings

Electrical Shock or Equipment Damage Hazard. Can shock, burn or cause equipment failure.

Disconnect power supply before installation.

Sensor failure

Please connect the sensor correctly according to your sensor selection setting.When it shows E0/E1 error, thermostat will stop working and the load will be off.

- E0: Built-in sensor open or short circuit
- E1: External sensor is short-circuited or disconnected.

Wiring

Note:

G4 is for water heating, G5 is for electric heating. GC is for water/gas boiler.